

Pos. No	Part code	Description
1	AQAB021001	handle
2	AQAB021002	handle cover
3	AQAB021003	decorative cover
4	AQAB021004	Six-pin waterproof switch
5	AQAB021005	Socket mounting bracket
6	AQAB021006	Speed adjustment shaft
7	AQAB021007	Socket sealing ring
8	AQAB021008	British socket
9	AQAB021009	speed control knob
10	AQAB021010	top cover
11	AQAB021011	Dust-off button
12	AQAB021012	Dust-off rod
13	AQAB021013	motor cover
14	AQAB021014	Air vent deflector
15	AQAB021015	Torsion spring for air vent damper
16	AQAB021016	motherboard
17	AQAB021017	Potentiometer board
18	AQAB021018	Connection line assembly
19	AQAB021019	power cord assembly
20	AQAB021020	Sealing ring on the motor
21	AQAB021021	Motor soundproofing foam
22	AQAB021022	Sealing ring
23	AQAB021023	motor
24	AQAB021024	Motor lower seal ring
25	AQAB021025	Motor cover long sealing strip
26	AQAB021026	Motor cover short sealing strip
27	AQAB021027	Container cover
28	AQAB021028	grille
29	AQAB021029	flap
30	AQAB021030	Flipping plate sealing patch
31	AQAB021031	grounded leaf spring
32	AQAB021032	Bucket lid sealing strip
33	AQAB021033	Safety valve assembly
34	AQAB021034	Bottom cover blue sealing strip
35	AQAB021035	Filter basket
36	AQAB021036	Hepa components
37	AQAB021037	Stainless steel container
38	AQAB021038	Locking buckle fixing base
39	AQAB021039	Locking snap connector block
40	AQAB021040	lock
41	AQAB021041	Suction port sealing ring
42	AQAB021042	sip
43	AQAB012024	Drainage port seat
44	AQAB012023	Drain port gasket
45	AQAB012025	Drain cover plate
46	AQAB012026	Drain cover sealing ring
47	AQAB012027	Drain plug cover
48	AQAB021048	Base hook
49	AQAB021049	base
50	AQAB021050	tripod
51	AQAB021051	caster
52	AQAB021052	floor brush
53	AQAB011029	Crevice nozzle
54	AQAB011031	Multi caliber adapter
55	AQAB021055	Bent handle assembly
56	AQAB011025	house assembly
57	AQAB021057	telescopic tube assembly
58	AQAB021058	Hose storage hook
59	AQAB011026	Paper filter bag
60	AQAB011027	Foam filter