

Pos. No	Part code	Description
1	EGAL011001	Nut
2	EGAL011002	Rubber foot
3	EGAL011003	Bolt
4	EGAL011004	Drain valve
5	EGAL011005	Tank
6	EGAL011006	Bolt
7	EGAL011007	Washer
8	EGAL011008	Wheel
9	EGAL011009	Nut
10	EGAL011010	Nut
11	EGAL011011	Safety valve
12	EGAL011012	Gasket
13	EGAL011013	Washer
14	EGAL011014	Bolt
15	EGAL011015	Pressure switch
16	EGAL011016	Wire
17	EGAL011017	Zip tie
18	EGAL011018	Terminal
19	EGAL011019	Plug
20	EGAL011020	Power plug
21	EGAL011021	Terminal
22	EGAL011022	Wire cover
23	EGAL011023	Electric board
24	EGAL011024	Wire lock
25	EGAL011025	Bolt
26	EGAL011026	Washer
27	EGAL011027	Screw
28	EGAL011028	Motor group
29	EGAL011029	Air filter
30	EGAL011030	Bolt
31	EGAL011031	Switch
32	EGAL011032	Upper cover
33	EGAL011033	Bolt
34	EGAL011034	Elbow
35	EGAL011035	Nut
36	EGAL011036	Washer
37	EGAL011037	Pipe
38	EGAL011038	Lower cover
39	EGAL011039	Rubber handle cover
40	EGAL011040	Gauge
41	EGAL011041	Quick coupler
42	EGAL011042	Pressure regulator
43	EGAL011043	Check valve
44	EGAL011044	Elbow
45	EGAL011045	Ring
46	EGAL011046	Gasket
47	EGAL011047	Pipe
Pump		
1	EGAL011048	Bolt
2	EGAL011049	Cylinder head
3	EGAL011050	Cylinder head gasket
4	EGAL011051	Valve plate
5	EGAL011052	Valve
6	EGAL011053	Gasket
7	EGAL011054	Gasket
8	EGAL011055	Cylinder
9	EGAL011056	Bolt
10	EGAL011057	Motor cover
11	EGAL011058	Gasket
12	EGAL011059	Washer
13	EGAL011060	Bearing
14	EGAL011061	Motor
15	EGAL011062	Zip tie
16	EGAL011063	Pipe
17	EGAL011064	Bearing
18	EGAL011065	Crankshaft
19	EGAL011066	Belt
20	EGAL011067	Connecting rod
21	EGAL011068	Piston ring
22	EGAL011069	Connecting rod cover
23	EGAL011070	Bolt
24	EGAL011071	Fan
25	EGAL011072	Washer
26	EGAL011073	Screw