



# User Manual

Spend a little Live a lot



## HIGH PRESSURE PIPE CLEANER



**Product  
Info**



[www.aldi.co.uk](http://www.aldi.co.uk)



Original instructions

# QR codes take you where you want to go quickly and easily

Whether you require **product information, spare parts** or accessories, details on **warranties** or **aftersales service**, or if you want to watch a **product demonstration video**, our QR codes will take you there in no time at all.

## What is a QR code?

A QR-code (QR=Quick Responses) is a type of matrix that can be read with a smartphone camera and contains a link to a website or contact details, for example.

**Advantage:** You are not required to manually enter a website address or contact details.

## How it works

To scan the QR code, all you need is a smartphone with QR code reader software and an internet connection\*. This type of software can be downloaded for free from your smartphone's app store.

## Try it out now

Just scan the QR code with your smartphone and find out more about the Aldi product you have purchased\*.



\*Depending on your tariff you may be charged for the connection.

# Content

<b>Introduction.....</b>	<b>4</b>
<b>General information and Safety instructions.....</b>	<b>4</b>
<b>Assembly and Parts List.....</b>	<b>7</b>
<b>Getting Started.....</b>	<b>8</b>
<b>Features.....</b>	<b>9</b>
<b>Instructions.....</b>	<b>9</b>
<b>FAQ.....</b>	<b>10</b>
<b>Other Useful Information.....</b>	<b>11</b>
<b>Warranty Card</b>	


# Introduction

This pipe cleaning set is intended for private use only.


- For unblocking sinks, pipes, drains and toilets.
- The pipe cleaning set is designed for use with the WORKZONE High pressure washer Q1W-SP05-2200A. The device is suitable for other pressure washers if the adaptor is used.


The appliance is suitable for the following pipes:

- Curve C no more than  $90^\circ$ ;
- Diameter D at least 40mm;
- Radius R at least 70mm.



## General information and safety instruction

 The following warning symbols appear throughout this assembly manual and indicate the appropriate safety measures you should take when assembling and operating the appliance.

 This symbol indicates there is a danger of serious personal injury or death if you do not observe the warning.

 **Attention!**  
Read all the instructions before using the appliance.



### CAUTION!

High pressure jets can be dangerous if subject to misuse. The jet must not be directed at persons, live electrical equipment or the appliance itself.

## General notes on safety

- **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.**
- **Never allow children or people unfamiliar with these instructions to use the appliance.** Local regulations may restrict the age of operator.
- **This appliance is manufactured in accordance with the relevant safety regulations.** To avoid danger, electrical appliances must only be repaired by qualified technicians.
- **Before operation, carefully check the appliance for damage.** Do not use the tool if any parts are damaged or defective. Have any damaged or defective parts repaired or replaced by an authorized service agent. Never attempt any repairs yourself.
- **Do not leave appliance unattended in the workplace.**
- **Switch on the pressure washer only when the pipe cleaning hose is at least up to the red marking in the pipe to be cleaned.**
- **Do not direct the jet against yourself or others in order to clean clothes and shoes.**
- During high pressure operation, do not pull the inserted hose completely out of the pipe to be cleaned. The high-pressure jet could cause injury.
- **The maximum water temperature must not exceed 60 °C.** The hose could be damaged.
- **To ensure appliance safety, use only original spare parts from the manufacturer or approved by the manufacturer.**
- **WARNING:** High pressure hoses, fittings and couplings are

important for the safety of the appliance. Use only hoses, fittings and couplings recommended by the manufacturer.

- Do not use the appliance if a supply cord or important parts of the appliance are damaged, e.g. safety devices, high pressure hoses, trigger gun.
- **Do not operate the appliance when fatigued or under the influence of alcohol or drugs.**
- **Do not stand on unstable surfaces.** Keep good footing and balance at all times.
- To reduce the risk of electrocution, keep all connections dry and off the ground. Do not touch plug with wet hands.
- **Disconnect from the electrical power supply before carrying out user maintenance.**
- **Store the appliance in a dry place and out of reach of children.**


## Technical specifications

High-pressure pipe cleaner	Q1W1523
Max. permissible pressure P max.	15Mpa
Length	15 m
Inlet flow temperature in max.	60°C

The pipe cleaner is designed for pressure washers working at a nominal pressure (p) of 90-150bar.

# Assembly and Parts List

Fig.2




1. Pipe cleaning set
2. Pipe cleaning hose
3. Connecting piece
4. Nozzle head
5. Adaptor H
6. Adaptor E
7. Pressure washer jet gun (sold separately)
8. Red safety marking

## Assembling

Fig.3

1. Connect the connecting piece (3) to the pressure washer spray gun.
2. Assemble the inlet water hose to your spray gun.




# Getting started



**Caution!** Ensure the pipe cleaner safety mark is fully inserted into the drain before switching on the pressure washer. The high-pressure jet could cause injury.

1. Insert the pipe cleaning hose into the pipe or drain, ensuring the red safety mark has fully disappeared.

Fig. 4



2. Switch on the pressure washer and squeeze the trigger on the spray gun .

When the trigger is released, water pressure is trapped in the discharge hose. Release trapped pressure by triggering the spray gun after the washer is turned off.


## Features

This pipe cleaning set comprises a nozzle head and a 15m long flexible hose which can be connected to a pressure washer. The hose is propelled through the pipe by the four high-pressure jets that are directed backwards and the blockage is released by the water jet.

## Instructions

1. Whilst the nozzle head is propelled through the pipe independently, feed in the pipe cleaning hose manually (Fig 5).

Fig. 5



2. To release blockages, squeeze the trigger several times in a row then release it (Fig 6).

Fig. 6



**Note!** Please ensure the cleaning hose is inserted past the red safety mark during high pressure operation. Failing to do so could cause injury.



## Frequently Asked Questions (FAQ)



**WARNING!** Only perform the steps described within these instructions! All further inspection, maintenance and repair work must be performed by an authorized service centre or a equal qualified specialist if you cannot solve the problem yourself!

Suspected malfunctions, disturbances or damages can often be fixed by the user themselves. The following troubleshoot table provides solutions to common problems encountered with the pipe cleaner.

Symptom	Possible cause	Solution
No pressure at the fluid nozzle	Air lock in the hose. blocked water inlet filter. Kink in water inlet hose. Blocked water supply.	Disconnect water hose from pressure washer, run water and reconnect. Clean or replace inlet filter. Remove kink. Turn on water supply. Check supply hose for leaks or blockage.
Low nozzle pressure	Unit not properly primed Insufficient inlet water supply Kink in water inlet hose Worn pump components	Prime unit Check water supply conditions Clean inlet screen Check with service agent
Appliance does not start	Not connected to power supply Power connection is not inserted correctly Switch malfunction Faulty motor	Connect to the main power supply Reconnect the unit to the mains Check with service agent Check with service agent


## Other useful information

### Adaptors

The enclosed adaptor H or adaptor E (5/6) may be helpful for use with other device. Plug-in and twist to connect the adaptor (5/6) to the high pressure spray gun.


- Adaptor H (emboss marked "H") can be connected to:  
WORKZONE spray gun SINCE 2012  
DURO spray gun SINCE 2012

Fig. 7



- Adaptor E (emboss marked "E") can be connected to:  
Gun of common used DIY market spray gun limited by 150bar

Fig.8



**NOTE:** To disconnect the adaptor from the gun, press this in the gun and turn it counterclockwise.

## WARNING

### Inspecting the device

Check all fastenings regularly. These can come loose over time because of the vibration.

## Waste disposal and environmental protection

### Disposal



Do not dispose of the packaging in your household waste.

The packaging is entirely made from recyclable materials. Dispose of the packaging in the appropriate recycling container.

### Service / customer support

Only have your tool serviced by a qualified specialist and use only original spare parts. This will ensure that the safety of the tool is maintained. Please contact our service partner if you have any queries or wish to order parts:

Sumec UK co. Ltd.  
Trading as Core Service  
Unit A & B, Escrick Business Park  
Escrick, York  
YO19 6FD  
United Kingdom

Tel: (GB) +44 (0)1904 727501 (IRE) +353 (0)1 902 2605  
E-mail: [support@coreservice.co.uk](mailto:support@coreservice.co.uk)  
Web: [www.coreservice.co.uk](http://www.coreservice.co.uk)

# WORKZONE<sup>®</sup> WARRANTY CARD

## HIGH PRESSURE PIPE CLEANER

Your detail:

Name \_\_\_\_\_

Address \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

 \_\_\_\_\_ E-Mail \_\_\_\_\_

Date of purchase \* \_\_\_\_\_

\* We recommend you keep the receipt with this warranty card.

Location of purchase \_\_\_\_\_



Description of malfunction :



If after contacting the manufacturer you are requested to return the faulty product please return the completed warranty card together with it.

Unit A&B  
Escrick Business Park  
Escrick  
York  
YO19 6FD  
UNITED KINGDOM  
support@coreservice.co.uk

### AFTER SALES SUPPORT

 GB +44 (0)1904 727501  [www.coreservice.co.uk](http://www.coreservice.co.uk)  
IRE +353 (0)1 902 2605

MODEL: Q1W1523 PRODUCT CODE: 94319 04/2017

The cost of calls from land-lines and mobiles may vary depending upon your service provider.  
Operating hours:  
08:00 am to 06:00 pm

**3**  
YEAR WARRANTY



## Warranty conditions

Dear Customer,

The **ALDI warranty** offers you extensive benefits compared to the statutory obligation arising from a warranty:

**Warranty period:** 3 years from date of purchase

**Costs:** Free repair/exchange or refund.  
No transport costs.

**Hotline:** The cost of calls from land-lines and mobiles may vary depending upon your service provider.

<b>ADVICE:</b> Please contact our service hotline by phone or e-mail before sending in the device. This allows us to provide support in the event of possible operator errors.
--

**In order to make a claim under the warranty, please send us:**

- Together with the faulty item the original receipt and the warranty card properly completed.
- The faulty product with all components included in the packaging.

---

**The warranty does not cover damage cause by:**

- **Accident or unanticipated events.** (e.g. lighting, water, fire)
- **Improper use or Transport.**
- **Disregard of the safety and maintenance instructions.**
- **Other improper treatment or modification.**

After the expiry of the warranty period, you still have the possibility to have your product repaired at your own expense. If the repair or the estimate of costs is not free of charge you will be informed accordingly in advance.

This does not affect your statutory rights.

---







**Spend a little** Live a lot

Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly. In the event of product failure within its intended use over the course of the first 3 years after date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product, please contact us via our helpline support services, details of which are to be found both in this manual and on the product itself.



**PRODUCED IN CHINA FOR:**

ALDI STORES LTD. PO BOX 26, ATHERSTONE  
WARWICKSHIRE, CV9 2SH.

---

ALDI STORES (IRELAND) LTD.  
PO BOX 726, NAAS, CO. KILDARE.  
Visit us at [www.aldi.com](http://www.aldi.com)

**AFTER SALES SUPPORT**

---



+44 (0)1904 727501  
+353 (0)1 902 2605



[www.coreservice.co.uk](http://www.coreservice.co.uk)

MODELL: Q1W1523

ARTIKELNUMMER: 94319

04/2017

**3**

**YEAR WARRANTY**